

Engine Inspection/Service

- Look for evidence of chewed wiring due to rodents.
- Thoroughly search for any signs of oil leaks.
- Check the coolant level/integrity of the overflow tank.
- Inspect the conditions of the coolant hoses and radiator cap, and replace if necessary.
- Test the diesel engine coolant with test strips (if diesel). Flush the coolant if required by mileage/date.
- Check the condition of the air cleaner.
- For diesels, the air-dryer filter should be replaced at least every 3 years.
- Maintain the fuel filter(s)/separator per service dates and mileage.
- Get the oil changed if required by mileage/date.
- Check the level of the windshield-washer fluid reservoir, and ensure the integrity of the rubber lines running to the pump and to the windshield.
- Check all fluid levels, even if a flush/change is not required by mileage or service date. This includes engine oil and transmission fluid.
- Check the condition of the battery. Inspect the battery for integrity, age, corrosion or loose cables. Charge, if needed. If the battery water needs to be topped off, now is a good time.

From the experts at:

MotorHome

Travel, Tech, Lifestyle – For the RV Enthusiast